

## EASY FIT BREAKAWAY CABLE



The **breakaway cable** is one of the most important mandatory components on the trailer. It needs regular checking and, if damaged, replacing. Knott has designed a simple method of replacement with a clevis and pin instead of a difficult burst ring. The carabiner style front fitting allows simple attachment to a fixed point on the towing vehicle.